SUPERIOR KNOWLEDGE - see MISREPRESENTATION. (11/90)

SUPPLEMENTARY CONDITIONS - the part of the contract documents which amends or supplements the general conditions. (11/90)

SUPPLIER - a manufacturer, fabricator, distributor or vendor. (11/90)

SURETY - a bonding company licensed to conduct business which guarantees the owner that the contract will be completed (Performance Bond) and that subcontractors and suppliers will be paid (Payment Bond). (11/90)

SUSPENSION OF WORK, CONSTRUCTIVE - an act or failure to act by the owner, or the owner's representative, which is not a directed suspension of work or work stoppage, but which has the effect of delaying, interrupting, or suspending all or a portion of the work. (11/90)

SUSPENSION OF WORK, DIRECTED - actions resulting from an order of the owner to delay, interrupt, or suspend any or all portions of the work for a given period of time, for the convenience of the owner. (11/90)

SYSTEM - a collection of hardware (equipment and facilities) and related software (procedures, etc) designated to perform a unique and useful function. A system contains everything necessary (except personnel and materials or supplies) to perform its defined function. (11/90)

SYSTEMS STUDIES - the development and application of methods and techniques for analyzing and assessing programs, activities and projects to review and assess efforts to date and to determine future courses and directions. These studies include cost/ benefit analysis, environmental impact analysis, assessment of the likelihood of technical success, forecasts of possible futures resulting from specific actions, and guidance for energy program planning and implementation. (11/90)

TAKE-OFF - a take-off is a specific type of quantification that is a measurement and listing of quantities of materials from drawings in order to support the estimate costing process and/or to support the material procurement process. Syn.: QUANTIFICATION. (1/03)

TANGIBLES - things that can be quantitatively measured or valued, such as items of cost and physical assets. (11/90)

TARGET DATE - the date an activity is desired to be started or completed; either externally imposed on the system by project management or client, or accepted as the date generated by the initial CPM schedule operation. (11/90)

TARGET REPORTING - a method of reporting the current schedule against some established base line schedule and the computations of variances between them. (11/90)

TARGET START DATE - see EXPECTED BEGIN DATE. (11/90)

TASK - Smallest unit of work planned. It must have an identifiable start and finish, and usually produces some recognizable results. (3/04)

aace .

April 13, 2004

TASK MONITOR - the individual assigned the monitoring responsibility for a major effort within the program. (11/90)

TAXES PAYABLE - tax accruals due within a year. (11/90)

TEMPORARY CONSTRUCTION COST - includes costs of erecting, operating, and dismantling impermanent facilities, such as offices, workshops, etc, and providing associated services such as utilities. (11/90)

TERMINATION - actions by the owner, in accordance with contract clauses, to end, in whole or in part, the services of the contractor. Termination may be for the convenience of the owner or for default by the contractor. (11/90)

TERMS OF PAYMENT - defines a specific time schedule for payment of goods and services and usually forms the basis for any contract price adjustments on those contracts that are subject to escalation. (11/90)

THIRD PARTY CLAIM - a claim against either or both the owner or the contractor by members of the public, or other parties, usually for property damage or personal injury. (11/90)

TIED ACTIVITY - an activity that must start within a specified time or immediately after its predecessor's completion or start. (11/90)

TIME EXTENSION - an increase in the contract time by modification to complete an item of work. Time extension may be granted under the corresponding provisions in the general conditions. An excusable delay generally entitles a contractor to a time extension. (11/90)

TIME HORIZON - see STUDY PERIOD. [A] (11/90)

TIME-LIMITED SCHEDULING - the scheduling of activities so predetermined resource availability pools are not exceeded unless the further delay will cause the project finish to be delayed. Activities can be delayed only until their late start date. However, activities will begin when the late start date is reached, even if resource limits are exceeded. Networks with negative total float time cannot be processed by time-limited scheduling. (11/90)

TIME NOW LINE - the point in time that the network analysis is based upon. May or may not be the data date. See STATUS LINE. (11/90)

TIME OF THE ESSENCE - a contract requirement that completion of the work within the time limits in the contract is essential. Failure to do so is a breach for which the injured party is entitled to damages. (11/90)

TIME-SCALED CPM - a plotted or drawn representation of a CPM network where the length of the activities indicates the duration of the activity as drawn to a calendar scale. Float is usually shown with a dashed line as are dummy activities. (11/90)

TIME UNIT - see CALENDAR UNIT. (11/90)

TIME VALUE OF MONEY - (1) the time-dependent value of money stemming both from changes in the purchasing power of money (that is, inflation or deflation), and from the real earning potential of



alternative investments over time. (2) the cumulative effect of elapsed time on the money value of an event, based on the earning power of equivalent invested funds. See FUTURE WORTH and PRESENT WORTH; (3) the expected interest rate that capital should or will earn. [B] (11/90)

TOTAL COST BIDDING - a method of establishing the purchase price of movable equipment; the buyer is guaranteed that maintenance will not exceed a set maximum amount during a fixed period and that the equipment will be repurchased at a set minimum price when the period ends. (11/90)

TOTAL COST MANAGEMENT - the effective application of professional and technical expertise to plan and control resources, costs, profitability and risks. Simply stated, it is a systematic approach to managing cost throughout the life cycle of any enterprise, program, facility, project, product, or service. This is accomplished through the application of cost engineering and cost management principles, proven methodologies and the latest technology in support of the management process. Can also be considered the sum of the practices and processes that an enterprise uses to manage the total life cycle cost investment in its portfolio of strategic assets. (1/02)

TOTAL FLOAT (TF) - the amount of time (in work units) that an activity may be delayed from its early start without delaying the project finish date. Total float is equal to the late finish minus the early finish or the late start minus the early start of the activity. (11/90)

TOTAL QUALITY MANAGEMENT - the consistent integrated orchestration of the total complex of an organization's work processes and activities to achieve continuous improvement in the organization's processes and products. (11/90)

TRACKING - a form of monitoring applied to projects. The measurements are expected to change according to the planned progress. [P] (11/90)

TRANSFER PRICE - a term used in economic analysis in the mineral processing industries; used to assign a value to raw materials when the same company does the mining and processing; usually equal to the fair market value. (11/90)

TRANSPORTATION PROBLEM - a homogeneous product is to be shipped in the amounts $a_1, a_2,...,a_m$ respectively from each of m shipping origins and received in amounts $b_1, b_2,...,b_n$ respectively by each of n shipping destinations. The cost of shipping a unit amount from the ith origin to the jth destination is c_{ij} and is known for all combinations (i,j). The problem is to determine the amounts x_{ij} to be shipped over all routes (i,j) so as to minimize the total cost of transportation. (11/90)

TRANSSHIPMENT PROBLEM - a generalized transportation problem in which transshipment through intermediate nodes between source and destination is allowed. (11/90)

TURNOVER RATIO - the ratio of annual sales to investment. Inclusion of working capital is preferable, but not always done. Turnover ratio is considered by some to be reasonable basis for a guesstimate of facilities cost, for new products similar to existing products. It ranges around 1.0 for many chemical plants. The product of turnover ratio and profit margin on sales gives a return-on-investment measure. (11/90)

UNBALANCING - A technique used in the pricing process to allocate estimated costs to accounts whose definitions do not fully reflect the nature of the cost being allocated. The purpose of unbalancing is to achieve a desired business result such as improved cash flow. For example, a disproportionate amount of overhead costs may be allocated in a contract bid to early project activities so that early income is maximized. (1/03)



UNCERTAINTY - unknown future events which cannot be predicted quantitatively within useful limits, eg, accidents which destroy invested facilities, a major strike, a competitor's innovation which makes the new product obsolete. (11/90)

UNDERGROUND FACILITIES - all pipelines, conduits, ducts, cables, wires, utility accessways, vaults, tanks, tunnels or other such facilities or attachments, and any encasements containing such facilities which have been installed underground to furnish any of the following services or materials: electricity, gases, steam, liquid petroleum products, telephone or other communications, cable television, sewage and drainage removal, traffic or other control systems or water. (11/90)

UNIT COST - dollar per unit of production. It is usually total cost divided by units of production, but a major cost divided by units of production is frequently referred to as a unit cost; for example, the total unit cost is frequently subdivided into the unit costs for labor, chemicals, etc. (11/90)

UNJUST ENRICHMENT DOCTRINE - the belief in law that one person should not be allowed to profit or enrich himself or herself unfairly at the expense of another person. (11/90)

UNUSUALLY SEVERE WEATHER - adverse weather which, at the time of year in which it occurred, is unusual for the place of contract performance. No matter how severe or destructive, if the weather is not unusual for the particular time and place, the contractor is not entitled to relief. Unusual or normal weather does not mean ideal weather or the best weather that can be expected; rather it means the normal weather pattern, both good and bad, that could be reasonably anticipated in a particular area. The normal weather pattern is generally that based on the record of the prior ten years unless the contract documents provide for a different period. (11/90)

UPDATING - the regular review, analysis, evaluation, and reporting of progress of the project, including recomputation of an estimate or schedule. See STATUSING. (11/90)

UNION - a group of workers who organize together for the purpose of negotiating wage rates, working conditions and fringe benefits. (11/90)

USEFUL LIFE - the period of time over which an investment is considered to meet its original objective. [A] (11/90)

USE VALUE - see FUNCTIONAL WORTH. (11/90)

VALUATION OR APPRAISAL - the art of estimating the fair-exchange value of specific properties. (11/90)

VALUE, ACTIVITY - that portion of the contract price which represents a fair value for the part of the work identified by that activity. (11/90)

VALUE ADDED BY DISTRIBUTION - the portion of the value of a product or service to the consumer or user which results from distribution activities. This value includes such components as time utility and place utility. (11/90)

VALUE ADDED BY MARKETING - that portion of the value of a product or service to the consumer or user which results from marketing activities. This value includes such components as price reduction through economies of scale and buyer awareness of more desirable innovations in products or services. (11/90)

VALUE OF WORK PERFORMED TO DATE - the planned cost for completed work. (11/90)

VALUE EFFECTIVE - generally used to describe decisions which have a cost impact; value-effective decisions tend to optimize the value received for the decision made and to maximize return on investments. (11/90)

VALUE ENGINEERING - a practice function targeted at the design itself, which has as its objective the development of design of a facility or item that will yield least life-cycle costs or provide greatest value while satisfying all performance and other criteria established for it. (11/90)

VALUE ENGINEERING COST AVOIDANCE - a decrease in the estimated overall cost for accomplishing a function. (11/90)

VALUE ENGINEERING COST REDUCTION - a decrease in the committed and/or established overall cost for accomplishing a function. (11/90)

VALUE ENGINEERING JOB PLAN - an aid to problem recognition, definition, and solution. It is a formal, step-by-step procedure followed in carrying out a value engineering study. (11/90)

VARIABLE COSTS - those costs that are a function of production, eg, raw materials costs, by-product credits, and those processing costs that vary with plant output (such as utilities, catalysts and chemical, packaging, and labor for batch operations). (11/90)

VARIANCE - in cost control, the difference between actual cost or forecast budget cost. (11/90)

VARIATION IN ESTIMATED QUANTITY - the difference between the quantity estimated in the bid schedule and the quantity actually required to complete the bid item. Negotiation or adjustment for variations are generally called for when an increase or decrease exceeds 15 percent. (11/90)

VENTURE LIFE - the total time span during which expenditures and/or reimbursements related to the venture occur. Venture life may include the research and development, construction, production and liquidation periods. See FINANCIAL LIFE. (11/90)

VENTURE WORTH - present worth of cash flows above an acceptable minimum rate, discounted at the average rate of earnings. (11/90)

VERTICAL EVENT NUMBERING - assigning event numbers in vertical order. (11/90)

WAGE RATE - the hourly, daily or weekly cost of a person who works for wages, e.g., mechanics, laborers, steamfitters. (11/90)

WEIGHTS - numerical modifiers used to infer importance of commodities in an aggregative index. (11/90)

WORK - any and all obligations, duties, responsibilities, labor, materials, equipment, temporary facilities, and incidentals, and the furnishing thereof necessary to complete the construction which are assigned to, or undertaken by the contractor, pursuant to the contract documents. Also, the entire completed construction or the various separately identifiable parts thereof required to be furnished under the contract documents. Work is the result of performing services, furnishing labor, and furnishing and incorporating materials and equipment into the construction, all as required by the contract documents. (11/90)

aace -

April 13, 2004

WORK BREAKDOWN STRUCTURE (WBS) - a product-oriented family tree division of hardware, software, facilities and other items which organizes, defines and displays all of the work to be performed in accomplishing the project objectives.

- 1. Contract Work Breakdown Structure (CWBS) the complete WBS for a contract developed and used by a contractor in accordance with the contract work statement. It extends the PSWBS to the lowest level appropriate to the definition of the contract work.
- 2. Project Summary Work Breakdown Structure (PSWBS) a summary WBS tailored by project management to the specific project with the addition of the elements unique to the project. (11/90)

WORK BREAKDOWN STRUCTURE ELEMENT - any one of the individual items or entries in the WBS hierarchy, regardless of level. (11/90)

WORK DIRECTIVE CHANGE - a written directive to the contractor, issued on or after the effective date of the agreement and signed by the owner and recommended by the engineer ordering an addition, deletion or revision in the work, or responding to differing or unforeseen physical conditions or emergencies under which the work is to be performed as provided in the general conditions. A work directive change may not change the contract price or the contract time, but is evidence that the parties expect that the change directed or documented by a work directive change will be incorporated in a subsequently issued change order following negotiations by the parties as to its effect, if any, on the contract price or contract time. (11/90)

WORKHOUR - an analysis of planned versus actual staffing of the project used to determine work progress, productivity rates, staffing of the project, etc. (11/90)

WORK-IN-PROCESS - product in various stages of completion throughout the factory, including raw material that has been released for initial processing and completely processed material awaiting final inspection and acceptance as finished product or shipment to a customer. Many accounting systems also include semifinished stock and components in this category. Syn: IN-PROCESS INVENTORY. (11/90)

WORK ITEM - the precedence notation equivalent of an activity. See ACTIVITY. (11/90)

WORK PACKAGE - a segment of effort required to complete a specific job such as a research or technological study or report, experiment or test, design specification, piece of hardware, element of software, process, construction drawing, site survey, construction phase element, procurement phase element, or service, which is within the responsibility of a single unit within the performing organization. The work package is usually a functional division of an element of the lowest level of the WBS. (11/90)

WORK POWER LEVELING - see LOAD LEVELING. (11/90)

WORK SAMPLING - A direct method of measuring and monitoring labor productivity so that labor resources can be minimized and wasted effort eliminated from work processes. Work sampling provides information about the work process (i.e., how work is done) in a way that supports statistical assessment of such processes in order to optimize productivity. (1/04)

WORK SITE - The area designated in the contract where the facility is to be constructed. (11/90)

WORK UNIT - a unit of time used to estimate the duration of activities. (11/90)

aace International

April 13, 2004

WORTH - the worth of an item or groups of items, as in a complete facility, is determined by the return on investment compared to the amount invested. The worth of an item is dependent upon the analysis of feasibility of the entire item or group or items under discussion (or examination). (11/90)

WRITTEN AMENDMENT - A written amendment of the contract documents, signed by the owner and the contractor on or after the effective date of the agreement and normally dealing with the non-engineering or non-technical rather than strictly work-related aspects of the contract documents. (11/90)

YEAR-TO-YEAR PRICE INDEX - a price index for a given year with the preceding year as the base period. (11/90)

YIELD - the ratio of return or profit over the associated investment, expressed as a percentage or decimal usually on an annual basis. See RATE OF RETURN. (11/90)



AACE International Recommended Practice No. 17R-97

COST ESTIMATE CLASSIFICATION SYSTEM

Acknowledgment:

Peter Christensen CCE, Primary Author Larry R. Dysert CCC, Primary Author Jennifer Bates CCE Dorothy J. Burton Robert C. Creese PE CCE John K. Hollmann PE CCE Kenneth K. Humphreys PE CCE Donald F. McDonald JR. PE CCE C. Arthur Miller Bernard A. Pietlock CCC Wesley R. Querns CCE Don L. Short II

Recommended Practice No. 17R-97

Cost Estimate Classification System



August 12, 1997

PURPOSE

As a recommended practice of AACE International, the Cost Estimate Classification System provides guidelines for applying the general principles of estimate classification to asset project cost estimates. Asset project cost estimates typically involve estimates for capital investment, and exclude operating and life-cycle evaluations. The Cost Estimate Classification System maps the phases and stages of asset cost estimating together with a generic maturity and quality matrix that can be applied across a wide variety of industries.

This guideline and its addenda have been developed in a way that:

- provides common understanding of the concepts involved with classifying project cost estimates, regardless of the type of enterprise or industry the estimates relate to;
- fully defines and correlates the major characteristics used in classifying cost estimates so that enterprises may unambiguously determine how their practices compare to the guidelines;
- uses degree of project definition as the primary characteristic to categorize estimate classes; and
- reflects generally-accepted practices in the cost engineering profession.

An intent of the guidelines is to improve communication among all of the stakeholders involved with preparing, evaluating, and using project cost estimates. The various parties that use project cost estimates often misinterpret the quality and value of the information available to prepare cost estimates, the various methods employed during the estimating process, the accuracy level expected from estimates, and the level of risk associated with estimates.

This classification guideline is intended to help those involved with project estimates to avoid misinterpretation of the various classes of cost estimates and to avoid their misapplication and misrepresentation. Improving communications about estimate classifications reduces business costs and project cycle times by avoiding inappropriate business and financial decisions, actions, delays, or disputes caused by misunderstandings of cost estimates and what they are expected to represent.

This document is intended to provide a guideline, not a standard. It is understood that each enterprise may have its own project and estimating processes and terminology, and may classify estimates in particular ways. This guideline provides a generic and generally-acceptable classification system that can be used as a basis to compare against. If an enterprise or organization has not yet formally documented its own estimate classification scheme, then this guideline may provide an acceptable starting point.

INTRODUCTION

An AACE International guideline for cost estimate classification for the process industries was developed in the late 1960s or early 1970s, and a simplified version was adopted as an ANSI Standard Z94.0 in 1972. Those guidelines and standards enjoy reasonably broad acceptance within the engineering and construction communities and within the process industries. This recommended practice guide and its addenda improves upon these standards by:

- 1. providing a classification method applicable across all industries; and
- 2. unambiguously identifying, cross-referencing, benchmarking, and empirically evaluating the multiple characteristics related to the class of cost estimate.

This guideline is intended to provide a generic methodology for the classification of project cost estimates in any industry, and will be supplemented with addenda that will provide extensions and additional detail for specific industries.

CLASSIFICATION METHODOLOGY

There are numerous characteristics that can be used to categorize cost estimate types. The most significant of these are degree of project definition, end usage of the estimate, estimating methodology, and the effort and time needed to prepare the estimate. The "primary" characteristic used in this guideline to define the classification category is the degree of project definition. The other characteristics are "secondary."

Categorizing cost estimates by degree of project definition is in keeping with the AACE International philosophy of Total Cost Management, which is a quality-driven process applied during the entire project life cycle. The discrete levels of project definition used for classifying estimates correspond to the typical phases and gates of evaluation, authorization, and execution often used by project stakeholders during a project life cycle.

Five cost estimate classes have been established. While the level of project definition is a continuous spectrum, it was determined from benchmarking industry practices that three to five discrete categories are commonly used. Five categories are established in this guideline as it is easier to simplify by combining categories than it is to arbitrarily split a standard.

The estimate class designations are labeled Class 1, 2, 3, 4, and 5. A Class 5 estimate is based upon the lowest level of project definition, and a Class 1 estimate is closest to full project definition and maturity. This arbitrary "countdown" approach considers that estimating is a process whereby successive estimates are prepared until a final estimate closes the process.

	Primary Characteristic		Secondary Characteristic				
ESTIMATE CLASS	LEVEL OF PROJECT DEFINITION Expressed as % of complete definition	END USAGE Typical purpose of estimate	METHODOLOGY Typical estimating method	EXPECTED ACCURACY RANGE Typical +/- range relative to best index of 1 [a]	PREPARATION EFFORT Typical degree of effort relative to least cost index of 1 [b]		
Class 5	0% to 2%	Screening or Feasibility	Stochastic or Judgment	4 to 20	1		
Class 4	1% to 15%	Concept Study or Feasibility	Primarily Stochastic	3 to 12	2 to 4		
Class 3	10% to 40%	Budget, Authorization, or Control	Mixed, but Primarily Stochastic	2 to 6	3 to 10		
Class 2	Class 2 30% to 70% Control or B		Primarity Deterministic	1 to 3	5 to 20		
Class 1	50% to 100%	Check Estimate or Bid/Tender	Deterministic	1	10 to 100		

Notes: [a] If the range index value of "1" represents +10/-5%, then an index value of 10 represents +100/-50%.

[b] If the cost index value of "1" represents 0.005% of project costs, then an index value of 100 represents 0.5%.

Figure 1 – Generic Cost Estimate Classification Matrix

DEFINITIONS OF COST ESTIMATE CHARACTERISTICS

The following are brief discussions of the various estimate characteristics used in the estimate classification matrix. For the secondary characteristics, the overall trend of how each characteristic varies with the degree of project definition (the primary characteristic) is provided.

Level of Project Definition (Primary Characteristic)

This characteristic is based upon percent complete of project definition (roughly corresponding to percent complete of engineering). The level of project definition defines maturity or the extent and types of input information available to the estimating process. Such inputs include project scope definition, requirements documents, specifications, project plans, drawings, calculations, learnings from past projects, reconnaissance data, and other information that must be developed to define the project. Each industry will have a typical set of deliverables that are used to support the type of estimates used in that industry. The set of deliverables becomes more definitive and complete as the level of project definition (i.e., project engineering) progresses.

End Usage (Secondary Characteristic)

The various classes (or phases) of cost estimates prepared for a project typically have different end uses or purposes. As the level of project definition increases, the end usage of an estimate typically progresses from strategic evaluation and feasibility studies to funding authorization and budgets to project control purposes.

Estimating Methodology (Secondary Characteristic)

Estimating methodologies fall into two broad categories: stochastic and deterministic. In stochastic methods, the independent variable(s) used in the cost estimating algorithms are generally something other than a direct measure of the units of the item being estimated. The cost estimating relationships used in stochastic methods often are somewhat subject to conjecture. With deterministic methods, the independent variable(s) are more or less a definitive measure of the item being estimated. A deterministic methodology is not subject to significant conjecture. As the level of project definition increases, the estimating methodology tends to progress from stochastic to deterministic methods.

Expected Accuracy Range (Secondary Characteristic)

Estimate accuracy range is in indication of the degree to which the final cost outcome for a given project will vary from the estimated cost. Accuracy is traditionally expressed as a +/- percentage range around the point estimate after application of contingency, with a stated level of confidence that the actual cost outcome would fall within this range (+/- measures are a useful simplification, given that actual cost outcomes have different frequency distributions for different types of projects). As the level of project definition increases, the expected accuracy of the estimate tends to improve, as indicated by a tighter +/- range.

Note that in figure 1, the values in the accuracy range column do not represent + or - percentages, but instead represent an index value relative to a best range index value of 1. If, for a particular industry, a Class 1 estimate has an accuracy range of +10/-5 percent, then a Class 5 estimate in that same industry may have an accuracy range of +100/-50 percent.

Effort to Prepare Estimate (Secondary Characteristic)

The level of effort needed to prepare a given estimate is an indication of the cost, time, and resources required. The cost measure of that effort is typically expressed as a percentage of the total project costs for a given project size. As the level of project definition increases, the amount of effort to prepare an estimate increases, as does its cost relative to the total project cost. The effort to develop the project deliverables is not included in the effort metrics; they only cover the cost to prepare the cost estimate itself.



RELATIONSHIPS AND VARIATIONS OF CHARACTERISTICS

There are a myriad of complex relationships that may be exhibited among the estimate characteristics within the estimate classifications. The overall trend of how the secondary characteristics vary with the level of project definition was provided above. This section explores those trends in more detail. Typically, there are commonalties in the secondary characteristics between one estimate and the next, but in any given situation there may be wide variations in usage, methodology, accuracy, and effort.

The level of project definition is the "driver" of the other characteristics. Typically, all of the secondary characteristics have the level of project definition as a primary determinant. While the other characteristics are important to categorization, they lack complete consensus. For example, one estimator's "bid" might be another's "budget." Characteristics such as "accuracy" and "methodology" can vary markedly from one industry to another, and even from estimator to estimator within a given industry.

Level of Project Definition

Each project (or industry grouping) will have a typical set of deliverables that are used to support a given class of estimate. The availability of these deliverables is directly related to the level of project definition achieved. The variations in the deliverables required for an estimate are too broad to cover in detail here; however, it is important to understand what drives the variations. Each industry group tends to focus on a defining project element that "drives" the estimate maturity level. For instance, chemical industry projects are "process equipment-centric"—i.e., the level of project definition and subsequent estimate maturity level is significantly determined by how well the equipment is defined. Architectural projects tend to be "structure-centric," software projects tend to be "function-centric," and so on. Understanding these drivers puts the differences that may appear in the more detailed industry addenda into perspective.

End Usage

While there are common end usages of an estimate among different stakeholders, usage is often relative to the stakeholder's identity. For instance, an owner company may use a given class of estimate to support project funding, while a contractor may use the same class of estimate to support a contract bid or tender. It is not at all uncommon to find stakeholders categorizing their estimates by usage-related headings such as "budget," "study," or "bid." Depending on the stakeholder's perspective and needs, it is important to understand that these may actually be all the same class of estimate (based on the primary characteristic of level of project definition achieved).

Estimating Methodology

As stated previously, estimating methodologies fall into two broad categories: stochastic and deterministic. These broad categories encompass scores of individual methodologies. Stochastic methods often involve simple or complex modeling based on inferred or statistical relationships between costs and programmatic and/or technical parameters. Deterministic methods tend to be straightforward counts or measures of units of items multiplied by known unit costs or factors. It is important to realize that any combination of methods may be found in any given class of estimate. For example, if a stochastic method is known to be suitably accurate, it may be used in place of a deterministic method even when there is sufficient input information based on the level of project definition to support a deterministic method. This may be due to the lower level of effort required to prepare an estimate using stochastic methods.

Expected Accuracy Range

The accuracy range of an estimate is dependent upon a number of characteristics of the estimate input information and the estimating process. The extent and the maturity of the input information as measured by percentage completion (and related to level of project definition) is a highly-important determinant of accuracy. However, there are factors besides the available input information that also greatly affect estimate accuracy measures. Primary among these are the state of technology in the project and the quality of reference cost estimating data.

State of technology—technology varies considerably between industries, and thus affects estimate accuracy. The state of technology used here refers primarily to the programmatic or technical uniqueness and complexity of the project. Procedurally, having "full extent and maturity" in the estimate basis deliverables is deceptive if the deliverables are based upon assumptions regarding uncertain technology. For a "first-of-a-kind" project there is a lower level of confidence that the execution of the project will be successful (all else being equal). There is generally a higher confidence for projects that repeat past practices. Projects for which research and development are still under way at the time that the estimate is prepared are particularly subject to low accuracy expectations. The state of technology may have an order of magnitude (10 to 1) effect on the accuracy range.

Quality of reference cost estimating data—accuracy is also dependent on the quality of reference cost data and history. It is possible to have a project with "common practice" in technology, but with little cost history available concerning projects using that technology. In addition, the estimating process typically employs a number of factors to adjust for market conditions, project location, environmental considerations, and other estimate-specific conditions that are often uncertain and difficult to assess. The accuracy of the estimate will be better when verified empirical data and statistics are employed as a basis for the estimating process, rather than assumptions.

In summary, estimate accuracy will generally be correlated with estimate classification (and therefore the level of project definition), all else being equal. However, specific accuracy ranges will typically vary by industry. Also, the accuracy of any given estimate is not fixed or determined by its classification category. Significant variations in accuracy from estimate to estimate are possible if any of the determinants of accuracy, such as technology, quality of reference cost data, quality of the estimating process, and skill and knowledge of the estimator vary. Accuracy is also not necessarily determined by the methodology used or the effort expended. Estimate accuracy must be evaluated on an estimate-by-estimate basis, usually in conjunction with some form of risk analysis process.

Effort to Prepare Estimate

The effort to prepare an estimate is usually determined by the extent of the input information available. The effort will normally increase as the number and complexity of the project definition deliverables that are produced and assessed increase. However, with an efficient estimating methodology on repetitive projects, this relationship may be less defined. For instance, there are combination design/estimating tools in the process industries that can often automate much of the design and estimating process. These tools can often generate Class 3 deliverables and estimates from the most basic input parameters for repetitive-type projects. There may be similar tools in other industry groupings.

It also should be noted that the estimate preparation costs as a percentage of total project costs will vary inversely with project size in a nonlinear fashion. For a given class of estimate, the preparation cost percentage will decrease as the total project costs increase. Also, at each class of estimate, the preparation costs in different industries will vary markedly. Metrics of estimate preparation costs normally exclude the effort to prepare the defining project deliverables.

ESTIMATE CLASSIFICATION MATRIX

The five estimate classes are presented in figure 1 in relationship to the identified characteristics. Only the level of project definition determines the estimate class. The other four characteristics are secondary characteristics that are generally correlated with the level of project definition, as discussed above.

This generic matrix and guideline provide a high-level estimate classification system that is nonindustry specific. Refer to subsequent addenda for further guidelines that will provide more detailed information for application in specific industries. These will provide additional information, such as input deliverable checklists, to allow meaningful categorization in that industry.



REFERENCES

ANSI Standard Z94.2-1989. Industrial Engineering Terminology: Cost Engineering.



AACE International Recommended Practice No. 18R-97

COST ESTIMATE CLASSIFICATION SYSTEM — AS APPLIED IN ENGINEERING, PROCUREMENT, AND CONSTRUCTION FOR THE PROCESS INDUSTRIES

TCM Framework: 7.3 - Cost Estimating and Budgeting

Acknowledgments:

Peter Christensen, CCE (Author) Larry R. Dysert, CCC (Author) Jennifer Bates, CCE Dorothy J. Burton Robert C. Creese, PE CCE John K. Hollmann, PE CCE Kenneth K. Humphreys, PE CCE Donald F. McDonald, Jr. PE CCE C. Arthur Miller Bernard A. Pietlock, CCC Wesley R. Querns, CCE Don L. Short, II AACE International Recommended Practice No. 18R-97

COST ESTIMATE CLASSIFICATION SYSTEM – AS APPLIED IN ENGINEERING, PROCUREMENT, AND CONSTRUCTION FOR THE PROCESS INDUSTRIES



TCM Framework: 7.3 - Cost Estimating and Budgeting

February 2, 2005

PURPOSE

As a recommended practice of AACE International, the Cost Estimate Classification System provides guidelines for applying the general principles of estimate classification to project cost estimates (i.e., cost estimates that are used to evaluate, approve, and/or fund projects). The Cost Estimate Classification System maps the phases and stages of project cost estimating together with a generic maturity and quality matrix, which can be applied across a wide variety of industries.

This addendum to the generic recommended practice provides guidelines for applying the principles of estimate classification specifically to project estimates for engineering, procurement, and construction (EPC) work for the process industries. This addendum supplements the generic recommended practice (17R-97) by providing:

- a section that further defines classification concepts as they apply to the process industries;
- charts that compare existing estimate classification practices in the process industry; and
- a chart that maps the extent and maturity of estimate input information (project definition deliverables)
 against the class of estimate.

As with the generic standard, an intent of this addendum is to improve communications among all of the stakeholders involved with preparing, evaluating, and using project cost estimates specifically for the process industries.

It is understood that each enterprise may have its own project and estimating processes and terminology, and may classify estimates in particular ways. This guideline provides a generic and generally acceptable classification system for process industries that can be used as a basis to compare against. It is hoped that this addendum will allow each user to better assess, define, and communicate their own processes and standards in the light of generally-accepted cost engineering practice.

INTRODUCTION

For the purposes of this addendum, the term process industries is assumed to include firms involved with the manufacturing and production of chemicals, petrochemicals, and hydrocarbon processing. The common thread among these industries (for the purpose of estimate classification) is their reliance on process flow diagrams (PFDs) and piping and instrument diagrams (P&IDs) as primary scope defining documents. These documents are key deliverables in determining the level of project definition, and thus the extent and maturity of estimate input information.

Estimates for process facilities center on mechanical and chemical process equipment, and they have significant amounts of piping, instrumentation, and process controls involved. As such, this addendum may apply to portions of other industries, such as pharmaceutical, utility, metallurgical, converting, and similar industries. Specific addendums addressing these industries may be developed over time.

This addendum specifically does not address cost estimate classification in nonprocess industries such as commercial building construction, environmental remediation, transportation infrastructure, "dry" processes such as assembly and manufacturing, "soft asset" production such as software development, and similar industries. It also does not specifically address estimates for the exploration, production, or transportation of mining or hydrocarbon materials, although it may apply to some of the intermediate processing steps in these systems.

The cost estimates covered by this addendum are for engineering, procurement, and construction (EPC) work only. It does not cover estimates for the products manufactured by the process facilities, or for research and development work in support of the process industries. This guideline does not cover the

OOCO

February 2, 2005

significant building construction that may be a part of process plants. Building construction will be covered in a separate addendum.

This guideline reflects generally-accepted cost engineering practices. This addendum was based upon the practices of a wide range of companies in the process industries from around the world, as well as published references and standards. Company and public standards were solicited and reviewed by the AACE International Cost Estimating Committee. The practices were found to have significant commonalities that are conveyed in this addendum.

COST ESTIMATE CLASSIFICATION MATRIX FOR THE PROCESS INDUSTRIES

The five estimate classes are presented in figure 1 in relationship to the identified characteristics. Only the level of project definition determines the estimate class. The other four characteristics are secondary characteristics that are generally correlated with the level of project definition, as discussed in the generic standard. The characteristics are typical for the process industries but may vary from application to application.

This matrix and guideline provide an estimate classification system that is specific to the process industries. Refer to the generic standard for a general matrix that is non-industry specific, or to other addendums for guidelines that will provide more detailed information for application in other specific industries. These will typically provide additional information, such as input deliverable checklists to allow meaningful categorization in those particular industries.

	Primary Characteristic		Secondary (Characteristic	
ESTIMATE CLASS	LEVEL OF PROJECT DEFINITION Expressed as % of complete definition	END USAGE Typical purpose of estimate	METHODOLOGY Typical estimating method	EXPECTED ACCURACY RANGE Typical variation in low and high ranges [a]	PREPARATION EFFORT Typical degree of effort relative to least cost index of 1 [b]
Class 5	0% to 2%	Concept Screening	Capacity Factored, Parametric Models, Judgment, or Analogy	L: -20% to -50% H: +30% to +100%	1
Class 4	1% to 15%	Study or Feasibility	Equipment Factored or Parametric Models	L: -15% to -30% H: +20% to +50%	2 to 4
Class 3	10% to 40%	Budget, Authorization, or Control	Semi-Detailed Unit Costs with Assembly Level Line Items	L: -10% to -20% H: +10% to +30%	3 to 10
Class 2	30% to 70%	Control or Bid/ Tender	Detailed Unit Cost with Forced Detailed Take-Off	L: -5% to -15% H: +5% to +20%	4 to 20
Class 1	50% to 100%	Check Estimate or Bid/Tender	Detailed Unit Cost with Detailed Take- Off	L: -3% to-10% H: +3% to +15%	5 to 100

me 5

Notes: [2] The state of process technology and availability of applicable reference cost data affect the range markedly.

The +/- value represents typical percentage variation of actual costs from the cost estimate after application of contingency (typically at a 50% level of confidence) for given scope.

[b] If the range index value of "1" represents 0.005% of project costs, then an index value of 100 represents 0.5%. Estimate preparation effort is highly dependent upon the size of the project and the quality of estimating data and tools.

Copyright 2005 AACE, Inc.

AACE International Recommended Practices

aace -

February 2, 2005

Figure 1. – Cost Estimate Classification Matrix for Process Industries CHARACTERISTICS OF THE ESTIMATE CLASSES

The following charts (figures 2a through 2e) provide detailed descriptions of the five estimate classifications as applied in the process industries. They are presented in the order of least-defined estimates to the most-defined estimates. These descriptions include brief discussions of each of the estimate characteristics that define an estimate class.

For each chart, the following information is provided:

- Description: a short description of the class of estimate, including a brief listing of the expected
 estimate inputs based on the level of project definition.
- Level of Project Definition Required: expressed as a percent of full definition. For the process
 industries, this correlates with the percent of engineering and design complete.
- End Usage: a short discussion of the possible end usage of this class of estimate.
- Estimating Methods Used: a listing of the possible estimating methods that may be employed to develop an estimate of this class.
- Expected Accuracy Range: typical variation in low and high ranges after the application of contingency (determined at a 50% level of confidence). Typically, this results in a 90% confidence that the actual cost will fall within the bounds of the low and high ranges.
- Effort to Prepare: this section provides a typical level of effort (in hours) to produce a complete
 estimate for a US\$20,000,000 plant. Estimate preparation effort is highly dependent on project size,
 project complexity, estimator skills and knowledge, and on the availability of appropriate estimating
 cost data and tools.
- ANSI Standard Reference (1989) Name: this is a reference to the equivalent estimate class in the
 existing ANSI standards.
- Alternate Estimate Names, Terms, Expressions, Synonyms: this section provides other
 commonly used names that an estimate of this class might be known by. These alternate names are
 not endorsed by this Recommended Practice. The user is cautioned that an alternative name may not
 always be correlated with the class of estimate as identified in the chart.

CLASS 5 ESTIMATE

Description:

Class 5 estimates are generally prepared based on very limited information, and subsequently have wide accuracy ranges. As such, some companies and organizations have elected to determine that due to the inherent inaccuracies, such estimates cannot be classified in a conventional and systemic manner. Class 5 estimates, due to the requirements of end use, may be prepared within a very limited amount of time and with little effort expended—sometimes requiring less than an hour to prepare. Often, little more than proposed plant type, location, and capacity are known at the time of estimate preparation.

Level of Project Definition Required: 0% to 2% of full project definition.

End Usage:

Class 5 estimates are prepared for any number of strategic business planning purposes, such as but not limited to market studies, assessment of initial viability, evaluation of alternate schemes, project screening, project location studies, evaluation of resource needs and budgeting, long-range capital planning, etc.

Estimating Methods Used:

Class 5 estimates virtually always use stochastic estimating methods such as cost/capacity curves and factors, scale of operations factors, Lang factors, Hand factors, Chilton factors, Peters-Timmerhaus factors, Gulhrie factors, and other parametric and modeling techniques.

Expected Accuracy Range:

Typical accuracy ranges for Class 5 estimates are - 20% to -50% on the low side, and +30% to +100% on the high side, depending on the technological complexity of the project, appropriate reference information, and the inclusion of an appropriate contingency determination. Ranges could exceed those shown in unusual circumstances.

Effort to Prepare (for US\$20MM project):

As little as 1 hour or less to perhaps more than 200 hours, depending on the project and the estimating methodology used.

ANSI Standard Reference Z94.2-1989 Name: Order of magnitude estimate (hypically -30% to +50%).

Alternate Estimate Names, Terms, Expressions, Synonyms:

Ratio, ballpark, blue sky, seat-of-pants, ROM, idea study, prospect estimate, concession license estimate, guesstimate, rule-of-thumb.

20Ce International

February 2, 2005

Figure 2a. - Class 5 Estimate

Description:

Class 4 estimates are generally prepared based on limited information and subsequently have fairly wide accuracy ranges. They are typically used for project screening, determination of feasibility, concept evaluation, and preliminary budget approval. Typically, engineering is from 1% to 15% complete, and would comprise at a minimum the following: plant capacity, block schematics, indicated layout, process flow diagrams (PFDs) for main process systems, and preliminary engineered process and utility equipment lists.

Level of Project Definition Required: 1% to 15% of full project definition.

End Usage:

Class 4 estimates are prepared for a number of purposes, such as but not limited to, detailed strategic planning, business development, project screening at more developed stages, alternative scheme analysis, confirmation of economic and/or technical feasibility, and preliminary budget approval or approval to proceed to next stage.

CLASS 4 ESTIMATE Estimating Methods Used:

Class 4 estimates virtually always use stochastic estimating methods such as equipment factors, Lang factors, Hand factors, Chilton factors, Peters-Timmerhaus factors, Guthrie factors, the Miller method, gross unit costs/ratios, and other parametric and modeling techniques.

Expected Accuracy Range:

Typical accuracy ranges for Class 4 estimates are -15% to -30% on the low side, and +20% to +50% on the high side, depending on the technological complexity of the project, appropriate reference information, and the inclusion of an appropriate contingency determination. Ranges could exceed those shown in unusual circumstances.

Effort to Prepare (for US\$20MM project):

Typically, as little as 20 hours or less to perhaps more than 300 hours, depending on the project and the estimating methodology used.

ANSI Standard Reference Z94.2-1989 Name: Budget estimate (typically -15% to + 30%).

Alternate Estimate Names, Terms, Expressions, Synonyms:

Screening, top-down, feasibility, authorization, factored, pre-design, pre-study.

Figure 2b. - Class 4 Estimate

CLASS 3 ESTIMATE

Description:

Class 3 estimates are generally prepared to form the basis for budget authorization, appropriation, and/or funding. As such, they typically form the initial control estimate against which all actual costs and resources will be monitored. Typically, engineering is from 10% to 40% complete, and would comprise at a minimum the following: process flow diagrams, utility flow diagrams, preliminary piping and instrument diagrams, plot plan, developed layout drawings, and essentially complete engineered process and utility equipment lists.

Level of Project Definition Required: 10% to 40% of full project definition.

End Usage:

Class 3 estimates are typically prepared to support full project funding requests, and become the first of the project phase "control estimates" against which all actual costs and resources will be monitored for variations to the budget. They are used as the project budget until replaced by more detailed estimates. In many owner organizations, a Class 3 estimate may be the last estimate required and could well form the only basis for cost/schedule control.

Estimating Methods Used:

Class 3 estimates usually involve more deterministic estimating methods than stochastic methods. They usually involve a high degree of unit cost line items, although these may be at an assembly level of detail rather than individual components. Factoring and other stochastic methods may be used to estimate less-significant areas of the project.

Expected Accuracy Range:

Typical accuracy ranges for Class 3 estimates are -10% to -20% on the low side, and +10% to +30% on the high side, depending on the technological complexity of the project, appropriate reference information, and the inclusion of an appropriate contingency determination. Ranges could exceed those shown in unusual circumstances.

Effort to Prepare (for US\$20MM project):

Typically, as little as 150 hours or less to perhaps more than 1,500 hours, depending on the project and the estimating methodology used.

ANSI Standard Reference Z94.2-1989 Name:

Budget estimate (typically -15% to + 30%).

Alternate Estimate Names, Terms, Expressions, Synonyms:

Budget, scope, sanction, semi-detailed, authorization, preliminary control, concept study, development, basic engineering phase estimate, target estimate.

Figure 2c. - Class 3 Estimate

aace International

February 2, 2005

CLASS 2 ESTIMATE

Description:

Class 2 estimates are generally prepared to form a detailed control baseline against which all project work is monitored in terms of cost and progress control. For contractors, this class of estimate is often used as the "bid" estimate to establish contract value. Typically, engineering is from 30% to 70% complete, and would comprise at a minimum the following: process flow diagrams, utility flow diagrams, piping and instrument diagrams, heat and material balances, final plot plan, final layout drawings, complete engineered process and utility equipment lists, single line diagrams for electrical, electrical equipment and motor schedules, vendor quotations, detailed project execution plans, resourcing and work force plans, etc.

Level of Project Definition Required: 30% to 70% of full project definition.

End Usage:

Description:

Class 2 estimates are typically prepared as the detailed control baseline against which all actual costs and resources will now be monitored for variations to the budget, and form a part of the change/variation control program.

Class 1 estimates are generally prepared for discrete parts

level of detail for the entire project. The parts of the project

subcontractors for bids, or by owners for check estimates.

be prepared for parts of the project to comprise a fair price

The updated estimate is often referred to as the current

control estimate and becomes the new baseline for cost/schedule control of the project. Class 1 estimates may

estimate or bid check estimate to compare against a

documentation of the project, and complete project

contractor's bid estimate, or to evaluate/dispute claims. Typically, engineering is from 50% to 100% complete, and would comprise virtually all engineering and design

or sections of the total project rather than generating this

estimated at this level of detail will typically be used by

Estimating Methods Used:

Class 2 estimates always involve a high degree of deterministic estimating methods. Class 2 estimates are prepared in great detail, and often involve tens of thousands of unit cost line items. For those areas of the project still undefined, an assumed level of detail takeoff (forced detail) may be developed to use as line items in the estimate instead of relying on factoring methods.

Expected Accuracy Range:

Typical accuracy ranges for Class 2 estimates are -5% to -15% on the low side, and +5% to +20% on the high side, depending on the technological complexity of the project, appropriate reference information, and the inclusion of an appropriate contingency determination. Ranges could exceed those shown in unusual circumstances.

Effort to Prepare (for US\$20MM project): Typically, as little as 300 hours or less to perhaps more than 3,000 hours, depending on the project and the estimating methodology used. Bid estimates typically require more effort than estimates used for funding or control purposes.

ANSI Standard Reference Z94.2-1989 Name: Definitive estimate (typically -5% to + 15%).

Alternate Estimate Names, Terms, Expressions, Synonyms:

Detailed control, forced detail, execution phase, master control, engineering, bid, tender, change order estimate.

Figure 2d. - Class 2 Estimate

CLASS 1 ESTIMATE Estimating Methods Used:

Class 1 estimates involve the highest degree of deterministic estimating methods, and require a great amount of effort. Class 1 estimates are prepared in great detail, and thus are usually performed on only the most important or critical areas of the project. All items in the estimate are usually unit cost line items based on actual design quantities.

Expected Accuracy Range:

Typical accuracy ranges for Class 1 estimates are -3% to -10% on the low side, and +3% to +15% on the high side, depending on the technological complexity of the project. appropriate reference information, and the inclusion of an appropriate contingency determination. Ranges could exceed those shown in unusual circumstances.

Effort to Prepare (for US\$20MM project):

Class 1 estimates require the most effort to create, and as such are generally developed for only selected areas of the project, or for bidding purposes. A complete Class 1 estimate may involve as little as 600 hours or less, to perhaps more than 6,000 hours, depending on the project and the estimating methodology used. Bid estimates typically require more effort than estimates used for funding or control purposes.

ANSI Standard Reference Z94.2 Name: Definitive estimate (typically -5% to + 15%).

Alternate Estimate Names, Terms, Expressions, Synonyms:

Full detail, release, fall-out, tender, firm price, bottoms-up, final, detailed control, forced detail, execution phase, master control, fair price, definitive, change order estimate.

Level of Project Definition Required: 50% to 100% of full project definition.

execution and commissioning plans.

End Usage:

Class 1 estimates are typically prepared to form a current control estimate to be used as the final control baseline against which all actual costs and resources will now be monitored for variations to the budget, and form a part of the changet/ariation control program. They may be used to evaluate bid checking, to support vendor/contractor negotiations, or for claim evaluations and dispute resolution.

Figure 2e. – Class 1 Estimate



AACE International Recommended Practices

aace -

February 2, 2005

COMPARISON OF CLASSIFICATION PRACTICES

Figures 3a through 3c provide a comparison of the estimate classification practices of various firms, organizations, and published sources against one another and against the guideline classifications. These tables permits users to benchmark their own classification practices.

AACE Classification Standard	ANSI Standard Z94.0	AACE Pro-1972	Association of Cost Engineers (UK) ACostE	Norwegian Project Management Association (MFP)	American Societ of Professional Estimators (ASPI	
				Concession Estimate		
Class 5	Order of Magnitude Estimate -30/+50	Order of Magnitude Estimate	Order of Magnitude Estimate Class IV -39/+30	Exploration Estimate	Leve l 1	
		Calluara		Feasibility Estimate		
Class 4	Budget Estimate	Study Estimate	Study Estimate Class III -20/+20	Authorization Estimate	Level 2	
Class 3	•15/+30	Preliminary Estimate	Budget Estimate Class -18/+19	Master Control Estimate	Level 3	
Class 2 Definitive Estimate		Definitive Estimate	Definitive Estimate	Current Control	Level 4	
Class 1	-5/+15	Detailed Estimate	Class 1-5/+5	Estimate	Level 5	
					Level 6	

Figure 3a. - Comparison of Classification Practices

aace International

February 2, 2005

	AACE Classification Standard	Major Consumer Products Company (Confidential)	Major Oli Company (Confidential)	Major Oil Company (Confidential)	Major Olt Compan (Confidential)	
_ -		Class S	Class V	Class A Prospect Estimate	Class V	
	Class 6	Strategic Estimate	Order of Magnitude Estimate	Class B Evaluation Estimate		
	Class 4	Class 1 Conceptual Estimale	Class IV Screening Estimate	Class C Feasibility Estimate	Class IV Class III	
		Conceptual Calmare	Class III	Class D Development Estimate		
	Class 3	Class 2 Semi-Detailed Estimate	Primary Control Estimate	Class E Preliminary Estimate		
	Class 2	Class 3	Class II Master Control Estimate	Class F Master Control Estimate	Class II	
	Class 1	Detailed Estimate	Class I Current Control Estimate	Current Control Estimate	Classi	

Figure 3b. - Comparison of Classification Practices

AACE Classification Standard	J.R. Heizelman, 1988 AACE Transactions [1]	K.T. Yeo, The Cost Engineer, 1989 [2]	Stevens & Davis, 1988 AACE Transactions [3]	P. Behrenbruck Journal of Petrotel Technology, 1993	
Class 5	Class V	Class V Order of Magnitude	Class III*	Order of Magnitus	
Class 4	Class IV	Class IV Factor Estimate		Sludy Eslimale	
Cinus 3	Class III	Class III Office Estimate	Class II		
Class 2	Class II	Class II Definitive Estimate		Budget Estimate	
Class 1	Class I	Class I Final Estimate	Class I	Control Estimate	

Figure 3c. - Comparison of Classification Practices

^[1] John R. Heizelman, ARCO Oil & Gas Co., 1988 AACE Transactions. Paper V3.7
[2] K.T. Yeo, The Cost Engineer, Vol. 27, No. 6, 1989
[3] Stevens & Davis, BP International Ltd., 1988 AACE Transactions, Paper B4.1 (* Class III is inferred)
[4] Peter Behrenbruck, BHP Petroleum Pty., Ltd., article in Petroleum Technology, August 1993

OOCE .

February 2, 2005

ESTIMATE INPUT CHECKLIST AND MATURITY MATRIX

Figure 4 maps the extent and maturity of estimate input information (deliverables) against the five estimate classification levels. This is a checklist of basic deliverables found in common practice in the process industries. The maturity level is an approximation of the degree of completion of the deliverable. The degree of completion is indicated by the following letters.

- None (blank): development of the deliverable has not begun.
- Started (S): work on the deliverable has begun. Development is typically limited to sketches, rough outlines, or similar levels of early completion.
- Preliminary (P): work on the deliverable is advanced. Interim, cross-functional reviews have usually been conducted. Development may be near completion except for final reviews and approvals.
- Complete (C): the deliverable has been reviewed and approved as appropriate.

	ESTIMATE CLASSIFICATION						
General Project Data:	CLASS 5	CLASS 4	CLASS 3	CLASS 2	CLASS 1		
Project Scope Description	General	Preliminary	Defined	Defined	Defined		
Plant Production/Facility Capacity	Assumed	Preliminary	Defined	Defined	Defined		
Plant Location	General	Approximate	Specific	Specific	Specific		
Soils & Hydrology	None	Preliminary	Defined	Defined	Defined		
Integrated Project Plan	None	Preliminary	Defined	Defined	Defined		
Project Master Schedule	None	Preliminary	Defined	Defined	Defined		
Escalation Strategy	None	Preliminary	Defined	Defined	Defined		
Work Breakdown Structure	None	Preliminary	Defined	Defined	Defined		
Project Code of Accounts	None	Preliminary	Defined	Defined	Defined		
Contracting Strategy	Assumed	Assumed	Preliminary	Defined	Defined		
Engineering Deliverables:							
Block Flow Diagrams	S/P	P/C	C	C	C		
Plot Plans		S	P/C	C	C .		
Process Flow Diagrams (PFDs)		S/P	P/C	С	C		
Utility Flow Diagrams (UFDs)		S/P	P/C	С	C		
Piping & Instrument Diagrams (P&IDs)		S	P/C	С	C		
Heat & Material Balances		S	P/C	С	C		
Process Equipment List		S/P	P/C	С	C		
Utility Equipment List		S/P	P/C	С	C		
Electrical One-Line Drawings		S/P	P/C	С	С		
Specifications & Datasheets		S	P/C	С	С		
General Equipment Arrangement Drawings		S	P/C	C	C		
Spare Parts Listings			S/P	Ρ	С		
Mechanical Discipline Drawings			S	P	P/C		
Electrical Discipline Drawings			S	Р	P/C		
Instrumentation/Control System Discipline Drawings			S	р	P/C		
Civil/Structural/Site Discipline Drawings			S	Р	P/C		

Figure 4. – Estimate Input Checklist and Maturity Matrix

REFERENCES

ANSI Standard Z94.2-1989. **Industrial Engineering Terminology: Cost Engineering**. AACE International Recommended Practice No.17R-97, **Cost Estimate Classification System**.

CONTRIBUTORS

Peter Christensen, CCE (Author) Larry R. Dysert, CCC (Author) Jennifer Bates, CCE

Copyright 2005 AACE, Inc.

aace .

February 2, 2005

Dorothy J. Burton Robert C. Creese, PE CCE John K. Hollmann, PE CCE Kenneth K. Humphreys, PE CCE Donald F. McDonald, Jr. PE CCE C. Arthur Miller Bernard A. Pietlock, CCC Wesley R. Querns, CCE Don L. Short, II

CSC.14



Construction Cost Contingency Tracking System

Mr. John F. Rowe, PE

he author will present an objective, forward-looking cost contingency tracking system (CTS) that uses readily available cost information and a simple agers can assign contingency to construction contracts, track its consumption and manage a reserve for upcoming work. The paper will discuss the development of rules, using the perceived risk of each construction contract, to assign an initial contingency value to each construction contract. The author will then describe setting up the CTS using this initially assigned contingency value, basic cost information and cost trends from field staff. Once in place, project managers can use the CTS to assess a project's overall budget health and focus on contracts that require special attention. The CTS can also be used to calculate the estimated cost at completion for each contract to provide early warning of overruns. It has been successfully tested on a \$1.4 billion rail and highway improvement program.

CONTINGENCY

The Association for Advancement of Cost Engineering defines contingency as, "An amount added to the estimate to allow for changes that experience shows will likely be required [5]. The value of possible changes, and thus contingency, is proportional to the risk present in a project and this risk drops as the design advances, construction contracts are awarded, and construction is completed. Figure 1 shows a downward sloping channel that represents total project contingency over the life cycle of a project. Typically, the baseline project budget is set at some point in the project life cycle and project managers must live within that contingency budget. Ideally, the baseline budget should not be set until the project manager has a good handle on the remaining project risk and can determine a sufficient value of contingency to include in the budget to cover that risk [1,2]. Although beyond the scope of this paper, much has been written about techniques to initially set the contingency budget including expert opinion, Monte Carlo analysis, and other statistical methods [3,4]. This paper will focus on managing that contingency budget once it has been set, specifically during the construction

phase of a capital project. This is accomplished by solving the twin problems of how to assign cost contingency to each construction contract and how to accurately forecast the final cost of these contracts at any given time.

readily available cost information and a simple spreadsheet format. Using the CTS, project managing capital projects. The pace quickens, spending accelerates, and manage a reserve for upcoming work. The cuss the development of rules, using the perceived onstruction contract, to assign an initial contingency construction contract. The author will then describe potential project contingency shortfalls in order to down-scope or CTS using this initially assigned contingency value, ormation and cost trends from field staff. Once in managers can use the CTS to assess a project's over-tilth and focus on contracts that require special attentions.

ASSIGNING CONTINGENCY TO CONSTRUCTION CONTRACTS

By the start of the construction phase, final design should be complete and most, if not all, risk associated with each contract should result from change order growth occurring after contract award. Since the engineer's estimate for a construction contract is only intended to predict the bid price of the contract, contingency must be included in the contract budget to account for change order growth.

Project managers should establish guidelines governing the amount of change order contingency to be assigned to each contract. A survey of past experience with change order growth on completed contracts can provide a good basis for setting these guidelines. Typically, since different types of contracts contain different levels of change order risk, initial contingency guidelines should take the contract type into account. Table 1 shows an example set of guidelines by contract type—the details will vary by project. Using established guidelines, the project team can quickly determine the desired contingency value to assign to each contract as its design is completed. The same guidelines will be used to reset the contingency based on the original contract value once bids are received on each contract. This initial contingency value (C₁) is a key numerical input to the CTS.

CSC.14.1